

1. Seat Height Adjustment



Lift the lever on the left-hand side and take your weight off the seat to raise the height. Remain seated to lower the height. Release the lever to lock the seat height.

View From Front



For further assistance please call
Customer Services on
0845 345 0898

2. Seat Tilt Adjustment



Lift the lever on the right-hand side to release the seat tilt lock. Tilt the seat whilst seated. Release the lever to lock the seat tilt.

View From Side

