

1. Seat Height



Lift up the front button on the right-hand side and take your weight off the seat to raise the height. Remain seated to lower the height. Release the button to lock the seat height.

2. Back Angle



Lift up the middle button on the right-hand side and take your weight off the back to bring it forward. Lean back to move it backwards. Release the button to lock the back angle.

3. Free Float Activation



Twist the knob on the right-hand side anti-clockwise to activate the seat rock. Twist the knob clockwise to lock the seat in any position.

4. Free Float Tension



Twist the knob under the front of the chair while in free float mode to adjust the tension of the rocking motion. Clockwise increases the tension, anti-clockwise reduces the tension.

5. Back Height



Lift up both buttons on the back rest to release the back height lock, then raise or lower the back. Release both buttons to lock the back height.

6. Seat Depth



Lift up the back button on the right-hand side and slide the seat backward or forward. Release the button to lock the seat depth.

7. Arm Rest (If fitted) Height



Lift up the button on the arm post to release the arm height lock. Raise or lower the arm. Release the button to lock the arm height. Repeat for the other arm.

8. Arm Rest Pivot



Rotate the arm until it locks at the desired position. Repeat for the other arm.

9. Arm Rest Width



Rotate the lever at the base of the arm to loosen the arm width lock. Slide the whole arm in or out. Rotate the lever back again to lock the arm. Repeat for the other arm.

10. Head/Neck Rest (If Fitted)



Pull the headrest post up to raise the height or push it down to lower the height. Rotate the knobs on either side of the neck rest to adjust the depth for varying support.

For further assistance please call
Customer Services on
0845 345 0898